





AlcoTorch V9 User Manual



This alcohol analyzer is only used to make a rapid, non-contact detection based on Ethyl Alcohol from the drivers, and features with powerful flashlight and baton.

STRUCTURE



DETAILED PROCEDURE

Alcohol Analyzer

- 1 Press and hold "On/Off Button" for 2 seconds to switch on the device.
- 2 Display shows "Ready".
- 3 Auto Test: Place the device in the front of the testee's mouth and nose and blow for 2-4 seconds. The device will test the air flow and do sampling automatically. Test result is displayed after test.
- 4 Passive Test: Press the "On/Off Button" to make a passive test. The device will take air samples continuously for a few seconds, move the device around the nose and the mouth of the testee during sampling. Test result is displayed after sampling.
- 5 Press "On/Off Button" for another test.

- 6 When displays “Ready”, press and hold the “On/Off Button” for 3 seconds to turn off the device. The device will be automatically turned off after 5 minutes.

Body Temperature Measurement


- 1 When displays “Ready”, press and hold the “Torch Button” for 3 seconds to enter body temperature measurement. Display shows “Body Temperature Measurement Ready”.
- 2 Place the device in front of the forehead within 2-5 cm, the body temperature will be displayed automatically.
- 3 Temperature below 34.1°C displays “LO”, above 42.9°C displays “HI”
- 4 Temperature Setting:
 - 4.1 Press and hold the “Flashlight Button” for 3 seconds to enter Temperature Setting.
 - 4.2 Unit: Select Celsius or Fahrenheit
 - 4.3 Compensation: Temperature measurement reading can be offset if it has error by increasing or decreasing the value.
 - 4.4 Reading: Select whether to display the exact reading or display only “Pass” or “Fail”.
 - 4.5 Alert: Set the alert value, default setting is 37.3°C

Flashlight & Torch

- 1 Press " Flashlight Button" to switch the flash frequencies between steady, flashing and off.
- 2 Press "Torch Button" to switch the Torch lights at the bottom of the handle.

Menu

When displays "Ready", press and hold the "Flashlight Button" for 3 seconds to enter Menu. Select the items by using the three buttons.



1. Records: Displays test records, 8000 test rerecords can be saved.
 2. Device Info: To check the serial number, software version and last calibration date of the device.
 3. Calibration: Refer to Calibration Instruction. Calibration option is protected by passwords and can only be operated by trained operator.
 4. Setting: Refer to Setting Instruction. Setting is protected by passwords and can only be operated by trained operator.
 5. Date & Time: Set date and time.
 6. Auto Off: Select whether the device is auto off. Default setting is auto off on, device will be switched off after 5 minutes.
 7. Flash: Select whether the flashlight is on when the test result is above Alarm level. Default setting is on.
- Current date and time are displayed on the bottom of the menu screen.

Charging the device

Connect USB cable and charge the device, a red light will be turned on when charging. The red light will be turned off when battery is fully charged. Charging time is about 3-4 hours.